




LED Floodlight + Motion Sensor

## Quick Start Guide

Smartsense is a motion sensing LED Floodlight that combines home security and energy efficiency in a simple-to-install form factor. Smartsense replaces the need for additional motion detection fixtures and requires very low maintenance. During normal operation, the Smartsense floodlight will turn on if it detects motion in the coverage area and remains lit for 90 seconds after no more motion is detected.

### Setting up your Smartsense

- 1 Make sure the power to the socket is off  
Screw in Smartsense bulb



- 2 Switch on the power. Smartsense will turn on automatically and begin initialization mode



- 3 The light will remain on for about 40 seconds during initialization
  - 4 After initialization, Smartsense will automatically turn off and enter sensing mode
- 

#### NOTE


- Smartsense requires constant power to operate
- Smartsense will not function properly if blocked or placed behind glass, plexiglass, or acrylic
- Please refer to the diagram below for Smartsense coverage area

#### CAUTION

- DO NOT USE WITH DIMMERS
- DO NOT DISASSEMBLE THE BULB



**No Dimmers**



**Detecting Area**